

# baby doll headboard

make  
in a  
day!

Make your little girl happy this weekend by constructing this sweet headboard to doll up her bedroom.

The perfect place for dolls - A headboard that doubles as a display case.

## Here's how:

1. Have all your timber cut to size at your local Timbercity.
  2. Lightly sand the pine blocks for smooth edges. Mount the pine blocks onto the 6mm back board with wood glue and screw from behind the board. Position one block at each corner, and one in the centre of the top and bottom (see pic right). Leave a 3mm gap at the top and bottom to fit the 6mm shelves.
  3. Glue the [4] x 6mm supawood shelves onto the blocks.
  4. Design a doll-shaped stencil and use this to mark out 6 dolls.
  5. Cut the doll shapes from corrugated plastic, or use your Dremel MultiTool to cut out shapes from 3mm perspex. Tape the dolls together across their backs. Push the dolls into place through the open ends of the headboard.
- DIY Tip:**  
If using a Dremel MultiTool to cut perspex, cut from left to right. Start with a rough cut and then finish off with a more detailed cut, sanding around the edges.
6. Drill a hole through each of the corner pine blocks and then attach the headboard to the wall with screws and wall plugs.
  7. Paint the supawood in your choice of colour. You can use any water-based, acrylic paint. Finish with a water-based glaze coat for added protection.



## You will need:

- [4] 6mm SupaWood 60 x 1000mm
  - [1] 6mm SupaWood 600 x 1000mm
  - [6] 50 x 50mm pine x 60mm long
  - Wood screws
  - Corrugated plastic, or perspex
  - Wall plugs and screws
- TOOLS:** Drill/Driver, Jigsaw, Impact/Hammer Drill, Dremel MultiTool with cutting disk or scroll saw.

Buy perspex offcuts from  
[www.plasticworld.co.za](http://www.plasticworld.co.za)



source - do it yourself magazine

**TIMBERCITY**

 **PG BISON**